


600MK4 - 850MK4 MILLIVOLT BURNER



INSTALLATION INSTRUCTIONS
FOR THE MILLIVOLT BURNER
MODEL 600MK4 - 850MK4
READ THESE INSTRUCTIONS CAREFULLY
BEFORE INSTALLING THE BURNER
TO AVOID DAMAGE TO THE BURNER
OR YOUR APPLIANCE.
SEE THE INSTALLATION MANUAL FOR
COMPLETE INSTRUCTIONS.





Model No. []
U.S.A. APPROVAL No. 60000

Input	Gas	Output	W.P.M.	W.P.M.	W.P.M.
1.0	1.0	1.0	1.0	1.0	1.0
1.5	1.5	1.5	1.5	1.5	1.5
2.0	2.0	2.0	2.0	2.0	2.0

FOR USE ON SEALS/VALVES/PILES/SHOULD BE USED FREQUENTLY
WITH PROPERLY TRAINED PERSONNEL ONLY AND UNDER NO CIRCUMSTANCES
OR AT ANY TIME SHOULD BE USED WITHOUT THE NECESSARY TRAINING &
EQUIPMENT. THIS APPLIANCE MAY BE USED AS A HEAT SOURCE.
**AFTER INSTALLING APPLIANCE
CHECK THAT CHIMNEY DRAWS PROPERLY**

**MILLIVOLT BURNER 600MK4-850MK4
AVAILABLE IN NAT AND LP GAS**

TO SUIT 600MK4 - 850MK4 MILLIVOLT BURNERS
NAT AND LP GAS



PIEZO & NUT
J-892116



ROCKER SWITCH
J-CARLINGH



GAS VALVE
NAT GAS J-820332
LP GAS J-820331



PILOT NAT GAS J-8227



PILOT LP GAS J-8422

MK4 BISCUIT
600MK4/700MK4 J-CERAMIC7
850MK4 J-CERAMIC8

